


驅動安裝：

1. 雙擊 CH341SER 圖標 Double click on the CH341SER icon



2. 點選安裝 Click to install



3. 等待幾分鐘安裝完成，點選“結束”即可成功安裝驅動。Wait for a few minutes for the installation to complete, click 'End' to install the driver successfully.

